L’Ami du Vin

Wein unter Schutzgas ausschenken



TEILE

1. Ausschankkopf mit Dichtung
2. Kugelmutter
3. Steigrohr
4. Schutzgasgeber
5. Hebel
6. Anschlussbolzen
7. Kapselhalter

Schutzgasgeber vorbereiten

1. Kapselhalter 7 abschrauben und die Schutzgaskapsel mit der Spitze nach oben einlegen.
2. Kapselhalter zügig und fest anschrauben. Sobald kein Zischen mehr zu hören ist, sitzt er richtig.

Ausschankkopf einsetzen

1. Flasche öffnen und den Ausschankkopf 1 mit seiner Dichtung in den Flaschenhals setzen.
2. Kugelmutter 2 lösen und das Steigrohr 3 so weit hineinschieben, dass es den Flaschenboden berührt.
3. Kugelmutter wieder anziehen. Das Steigrohr ist jetzt fixiert und abgedichtet.

Ausschenken

1. Schutzgasgeber 4 mit dem Anschlussbolzen 6 in die Öffnung des Ausschankkopfs stecken.
2. Hebel 5 langsam drücken. Das Schutzgas strömt in die Flasche und drückt den Wein durch das Steigrohr ins Glas.
3. Hebel loslassen – der Ausschank stoppt, die Flasche ist wieder drucklos.

ℹ Gas sparen: Den Hebel schon loslassen, wenn das Glas fast voll ist. Der Wein fließt noch etwas nach.

Zwischen den Ausschankvorgängen ist die Flasche drucklos, der Wein nimmt also kein Gas auf. Das Schutzgas liegt auf der Weinoberfläche und schützt ihn vor Sauerstoff. Die kleine Oberfläche im Steigrohr spielt dabei keine Rolle.

Kapseln

Nur Wecomatic Weinschutzkapseln 8 g Distickstoffmonoxid (N_2O) (Art.-Nr. T-KA-02010) verwenden, keine Sahne- oder Sodakapseln.

! Den Kapselhalter nie abschrauben, solange noch Gas in der Kapsel ist.

L’Ami du Vin

Serve wine under protective gas



PARTS

1. Dispensing head with seal
2. Ball nut
3. Riser tube
4. Gas dispenser
5. Lever
6. Connecting bolt
7. Capsule holder

Preparing the gas dispenser

1. Unscrew the capsule holder 7 and insert the protective gas capsule with the tip pointing upwards.
2. Screw the capsule holder back on quickly and firmly. Once the hissing stops, it is correctly seated.

Fitting the dispensing head

1. Open the bottle and place the dispensing head 1 with its seal in the neck of the bottle.
2. Loosen the ball nut 2 and push the riser tube 3 down until it touches the bottom of the bottle.
3. Tighten the ball nut again. The riser tube is now fixed and sealed.

Serving

1. Insert the gas dispenser 4 with its connecting bolt 6 into the opening of the dispensing head.
2. Press the lever 5 slowly. The gas flows into the bottle and pushes the wine through the riser tube into the glass.
3. Release the lever – the flow stops and the bottle is unpressurised again.

ℹ Save gas: release the lever when the glass is almost full. A little more wine will still flow.

Between servings the bottle is unpressurised, so the wine does not absorb any gas. The gas lies on the surface of the wine and protects it from oxygen. The small surface in the riser tube can be neglected.

Capsules

Only use Wecomatic wine protection capsules 8 g nitrous oxide (N_2O) (item no. T-KA-02010), no cream or soda capsules.

! Never unscrew the capsule holder while there is still gas in the capsule.